

			**/10 Part Number	**/13 Part Number	**/20 Part Number
103	Cover, drive end	1			
104	Cover, non-drive end	1			
109	Casing	1			
137.1	Port plate, drive end	1			
137.2	Port plate, non-drive end	1			
147.1/2	Manifold	2			
210	Shaft	1			
230	Impeller	1			
235/240	Bearing abutment	2			
235	Bearing abutment	2			
235	Bearing abutment	2			
235	Bearing abutment	2			
241	Circlip	1			
321/322	Bearing	2			
357/.1	Bearing housing	2			
360	Valve plate	2			
364	Mechanical seal housimg	2			
400	Gasket	4			
400.1	Gasket	2			
404	O-Ring	2			
405	Radial lip seal	2			
407/.1	Liq 6.24 147.				